


NORAMCO FITNESS

13901 Highway 105 West
Conroe, TX 77304

www.NoramcoFitness.com

v3 Display Button Wiring Diagram



As seen from the back side of the display board.

Each button will use a pair (2) of quick disconnect blades, as pictured above.

If you have any questions, please call our service department at (800)827-2017.